Coromandel	COROMANDEL INTERNATIONAL LIMITED Sarigam	Doc No. : INST/ SOP/ 19	
Issue No.01	DEPARTMENTAL MANUAL OF INSTRUMENT	Issue/ Revision Date: 02/10/2017	
Revision: 00	Title: SAFE OPERATING PROCEDURE FOR TSS METER CAL & PM	Page 1 of 2	

1.0 PURPOSE:

Calibration & preventive maintenance of TSS meter to maintain reliability.

2.0 SCOPE:

This procedure is applicable for calibration & preventive maintenance of TSS meter/sensor in ETP.

3.0 **DEFINITION:**

NIL

4.0 PROCEDURE:

- 4.1 Take work permit from the shift in charge to disconnect TSS Meter from the process line.
- 4.2 Remove the sensor and rinse with normal water.
- 4.3 Clean thoroughly with tissue paper.
- 4.4 Put the sensor in distilled water, it shows the reading zero.
- 4.5 If the indication deviates then do proper cleaning and check again.
- 4.6 After calibration install the sensor in process line and handover the equipment to the shift in charge of the plant.
- 4.7 Calibration record should be maintain in DOC No.: OF/EN/09
- 4.8 Preventive maintenance record should be maintain in format no: INST/F/06
- 4.9 Close the permit.

5.0 FREQUENCY:

- 5.1 At the time of initial startup after shutdown of more than two weeks.
- 5.2 After every 6 months, if plant is running.

6.0 RESPONSIBILITIES:

1) Asst. Manager/Sr. Officer/ Area in-charge (Inst.):

Prepared By:	Reviewed By:	Approved By:
Name :	Name :	Name :
Date :	Date :	Date :

Coromandel	COROMANDEL INTERNATIONAL LIMITED Sarigam	Doc No. : INST/ SOP/ 19	
Issue No.01	DEPARTMENTAL MANUAL OF INSTRUMENT	Issue/ Revision Date: 02/10/2017	
Revision: 00	Title: SAFE OPERATING PROCEDURE FOR TSS METER CAL & PM	Page 2 of 2	

7.0 ACCOUNTABILITY

Section Head

8.0 RECORDS:

Calibration Reports should be maintained for one year.

9.0 ATTACHMENTS:

Sr. No.	Format	Format No.
1	Calibration record	QF/EN/09
2	Preventive maintenance check point	INST/F/06

10.0 CHANGE RECORD:

Date	REV.	CHANGES INCORPORATED	
	NO.		
02/10/2017	00	Original Issue	

** END OF PROCEDURE **

Prepared By:	Reviewed By :	Approved By :
Name :	Name :	Name :
Date :	Date :	Date :